

**GM/CHEVY G0001 INSTALLATION INSTRUCTIONS**

Unscrew and unplug the factory roof lights. Plug the factory roof light harness into your new AtomicLED lights. Run each of the five wires from your AtomicLED lights to the included LED flasher. Connect the drivers side light to output# 1, connect the passenger side light to output# 5. The large center light will have three wires for the warning mode, the colors are as follows: white connects to output# 2, yellow connects to output# 3 and red connects to output# 4. Screw in the AtomicLED lights to your trucks roof. Interrupt the power going to the roof lights in the windshield pillar, the wire coming from the truck connects to the R/L in pin on the flasher, the wire coming from the roof lights connects to the R/L out pin on the flasher. Connect the ground on the flasher to a ground on your truck. Run a fused 12v(+) wire to a switch, then from the switch to the pos(+) pin on the flasher. To change the flash pattern, touch 12v(+) power to the scan lock pin on the flasher. \*\*\* FOR ALL WARRANTY ISSUES, PLEASE CONTACT ATOMICLED\*\*\*

